


COLLINGWOOD TOWN HALL SITE PLAN

Accessible areas are white on map.
 Inaccessible areas are shaded yellow.
 There will be two main entry points, both along Stanton Street.
 There are two main exits, both on the Eastern Wall which both lead towards Eddy Court and the Collingwood Train Station.



Collingwood Town Hall is serviced by the Epping/Hurstbridge line.
 Several bus lines run along Hoddle St including: 313 & 315 from Collins Street and 302-3 from Queen Street.

