



How to connect your windows-based laptop to Jack Dyer TV screen.



Wired Connection

1. Turn on TV screen by pressing button located on panel.
2. Locate the HDMI input on wall below the TV screen.
3. Connect your HDMI cable from the output of your device to the HDMI input below screen.

Wireless Connection

1. Turn on TV screen, pressing button located on panel.
2. Press windows icon plus K icon on your laptop.  + K
3. Enter code displayed on the TV screen, (located on the bottom of screen on the left-side).
4. Press ok on your laptop to connect.

Audio

1. Audio levels through HDMI and other inputs can be controlled by pressing the  icon.

(Check levels on your device to ensure they are not muted.)